

## Pontoonstuff.com “Quick Connect” Gauge panel Installation

- 1) Cut out the captain’s stand using provided dimensions. Ensure proper clearance behind panel assembly (steering mechanism, stereo, cup holders, support braces, etc)
- 2) Rotate adjustment screw on back of tachometer to match number of cylinders on your outboard engine.
- 3) Install panel using #8 pan head screws. Please note that over-tightening will cause the panel corners to break.
- 4) Wires from the **Pontoonstuff.com “Quick Connect” Gauge panel** are connected directly to the existing outboard engine harness on your boat.
- 5) Your new Pontoonstuff.com “Quick Connect” Gauge panel comes with standard bullet connectors to connect to most outboard engine harnesses.
- 6) The wire functions are
  - a. Purple – Ignition power (switched battery + power)
  - b. Black - battery negative ground wire
  - c. Gray – tachometer signal
  - d. Brown w/white stripe – trim position

Current outboard engine wire colors are

Mercury

Purple – ignition power  
Black – battery negative ground wire  
Gray – tachometer signal  
Brown w/white stripe – trim position

BRP

Purple – ignition power  
Black – battery negative ground wire  
Gray – tachometer signal  
Brown w/white stripe – trim position

Yamaha

Xxxx – ignition power  
Xxxx – battery negative ground wire  
Xxxx – tachometer signal  
Xxxx – trim position

Suzuki

Xxxx – ignition power  
Xxxx – battery negative ground wire  
Xxxx – tachometer signal  
Xxxx – trim position